



LOCATE THE HYDRANT BETWEEN THE BACK OF CURB AND THE FRONT OF THE SIDEWALK - INSTALL PLUMB WITH THE NOZZLES FACING THE STREET