

LOCATE THE HYDRANT BETWEEN THE BACK OF THE CURB
& THE FRONT OF THE SIDEWALK. INSTALL PLUMB WITH
THE NOZZLES FACING THE STREET.

